






KUPATILSKA GALANTERIJA











KOMADNA GALANTERIJA

MODEL 80600









Kataloški broj		Šifra	Naziv	Cena
80638		265	Držać čaše	473
80639		266	Držać za sapun - staklo	465
80651		267	Držać za sapun - žičani	524
80633		268	Držać toalet papira	532
80635		269	Držać za bade mantil	392
80632		270	Držać malog peškira	497
80624		271	Držać peškira 60 cm	798
80650		272	Držać za WC četku	1.021
80625		273	Držać peškira - dupli	1.287
80638A		274	Dozer za tečni sapun	702
80633A		275	Držać papirnog ubrusa	622
80633C		1342	Držać papirnog ubrusa sa poklopcem	930
80652		1611	Držać čaše dupli	774



MODEL 50700









50733		286	Držać toalet papira	622
50735		287	Držać za bade mantil	444


50738		288	Držač čase	679
50739		289	Držač za sapun - staklo	643
50751		290	Držač za sapun - žičani	598
50732		291	Držač malog peskira	598
50724		292	Držač peskira 60cm	1.271
50738-A		293	Dozer za tečni sapun	919
50750		294	WC četka sa poklopcem	1.196
50752		295	Držač čaše dupli	919
50737		296	Etažer	1.370
50733-A		297	Držač papirnog ubrusa	699


MODEL 20700














20733		1886	Držač toalet papira	767
20735		1885	Držač za bade mantil	486
20738		1887	Držač čase	962
20739		1888	Držač za sapun - staklo	962
20732		1889	Držač malog peskira	1.107
20724		1890	Držač peskira	1.998
20725		1891	Držač peskira dupli	3.015
20738A		3052	Dozer sapuna	1.437

20750		1892	Držáč za WC četku	1.618
20737		1893	Etažer stakleni	1.512




MODEL 9000				
9033		2374	Držáč toalet papira	790
9035		2375	Držáč za bade mantil	399
9038		2372	Držáč čase	971
9039		2373	Držáč za sapun - keramika	971
9032		2376	Držáč malog peskira	1.399
9024		2377	Držáč peskira	1.456
9025		2378	Držáč peskira dupli	2.047
9050		2380	Držáč za WC četku	2.097
9038A		2379	Dozer za tečni sapun	1.399










KUPATILSKA GALANTERIJA 6/1 SET				
7500		310	Galanterija - SET 6/1	3.190
8300		311	Galanterija - SET 6/1	3.368
80600		312	Galanterija - SET 6/1	3.015
70700		313	Galanterija - SET 6/1	3.855
3100		1612	Galanterija - SET 6/1	1.994

SBA GALANTERIJA MODEL1100				
FA1106		3055	Držáč čaše	1.088









FA1105		3054	Držač za sapun - keramički	1.109
FA1110		2462	Držač za sapun - žičani	1.736
FA1108		2461	Držač toalet papira	1.109
FA1111		1884	Držač za bade mantil	789
FA1109		3057	Držač malog peškira	905
FA1103		1881	Držač peškira 60 cm	1.489
FA1102		1882	Držač peškira - dupli	2.166
FA1115		2459	Polica dvodelna - staklo	3.951
FA1104		3053	Stakleni etažer	2.087
FA1113		2681	Držač za Wc četku - duži sa poklopcem	1.741
FA1108A		3056	Držač papirnog ubrusa	1.168
FA1107		2460	Držač čaše dupli	1.533
FA1112		2463	Dozer za tečni sapun	1.277







SBA GALANTERIJA MODEL 1300

1322		2575	Držač sa 2 kuke	325
1344		2574	Držač sa 4 kuke	613
1308			Držač toalet papira	682

1308P		1883	Držać toalet papira sa poklopcem	904
1306			Držać čaše	613
1305			Držać sapuna - staklo	690
1303		3460	Držać peškira	1.787
1312			Dozer za tečni sapun	974
1314		2692	Držać peškira pomični	2.318
1313			Držać za wc četku	1.091
1307			Držać čaše dupli	1.002
1304			Stakleni etažer	1.809

SBA GALANTERIJA MODEL1200

1206			Držać čaše	851
1205			Držać za sapun - keramički	851
1210			Držać za sapun - žičani	1.154
1208		4023	Držać toalet papira	737
1211		4022	Držać za bade mantil	511
1209			Držać malog peškira	649
1203			Držać peškira 60 cm	1.135
1202			Držać peškira - dupli	1.585

1204			Stakleni etažer	1.345
1213		4021	Držać za Wc četku - duži sa poklopcem	1.359
1208A			Držać papirnog ubrusa	703
1208P			Držać papirnog ubrusa sa poklopcem	1.162
1207			Držać čaše dupli	1.199
1212			Dozer za tečni sapun	1.247